



**Montážní(y) návod 86.**

Assembly instructions 86.


Montageanleitung 86.

FKP 800	H-FKP 800 S, H-UKP S
FKP 1200	H-FKP 1200 S, H-UKP S
FKP 1400	H-FKP 1400 S, H-UKP S
FKP 1600	H-FKP 1600 S, H-UKP S
FKP 1800	H-FKP 1800 S, H-UKP S
FKD 800	H-FKD 800 S, H-UKD S
FKD 1200	H-FKD 1200 S, H-UKD S
FKD 1400	H-FKD 1400 S, H-UKD S
FKD 1600	H-FKD 1600 S, H-UKD S
FKD 1800	H-FKD 1800 S, H-UKD S


<b>H-UKD S</b>	8 ks	
	4 ks	
<b>H-UKP S</b>	4 ks	




**1a**




**2a**



**1b**



**2b**



**3b**

