










Montážní(y) návod 96.

Assembly instructions 96.

Montageanleitung 96.

GATE

GP 902 L(P)	H-T 90 L(P) S, H-R 6 S, H-TR 90 S
GP 452	H-T 45 S, H-R 6 S, H-TR 45 S

H-R 6 S	4 ks	
	4 ks	
	4 ks	
	4 ks	
	8 ks	
	1 ks	
	2 ks	
	1 ks	
	3 ks	
	4 ks	